# DOL Diagnostic Online - Quick Start

Diagnostic Online

1. Make sure that the internet access is okay on the laptop.

2. Connect to the website: www.autoland-dol.com

3. Download "DOL Installation File" and install.

4. Confirm the connection is okay among the vehicle, OB91 VM and the laptop.

5. Start **DOL** on desktop to diagnose.

Features

OB91 VM

RJ45 RS-232 COM 1 COM 2 DC+12V

Connection

● Connection via Bluetooth Dongle ●
4-digit Pairing Pin Code: 5191

BT-01 BLT
AC-EC1
OBDII-AC-16P

● Connection via RS 232 Com ●

DB9F-5M
AC-EC1
OBDII-AC-16P

● Connection via USB Port ●

RU-C (USB to RS-232 convert cable, please install driver first)
AC-EC1
OBDII-AC-16P
DB9F-5M

AUTOLAND®
SCIENTECH